

Procedure Responsibilities and Authorisation

Department Responsible for Procedure	NICU		
Document Facilitator Title	Leanne Baker		
Document Facilitator Name	Registered Nurse & Nurse Educator		
Document Owner Title	Charge Nurse Manager		
Document Owner Name	Chantelle Hill		
Target Audience	Nurses		
Displaiment This desumant has been developed by W	Voikata District Haalth Doord an acifically for its own		

Disclaimer: This document has been developed by Waikato District Health Board specifically for its own use. Use of this document and any reliance on the information contained therein by any third party is at their own risk and Waikato District Health Board assumes no responsibility whatsoever.

Procedure Review History

Version	Updated by	Date Updated	Description of Changes
5	Leanne Baker, Richard Pagdanganan, and Ancy Jose	Dec 2017	3 yearly update
4	Leanne Baker	March 2013	3 yearly update
3	Leanne Baker, Jenni Richards & Tiv Pilapitiya	Jan 2010	Practice change – Bundles of care introduced

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021	
Facilitator	acilitator Title Registered Nurses NICU				Department:	NICU		
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING								



Contents

1.	Ove	rview	3
	1.1	Purpose	3
	1.2	Scope For neonates	3
	1.3	Patient Groups Neonates and infants in NICU	3
	1.4	Definitions	3
2.	Clin	ical Management	5
	2.1	Competency required	5
	2.2	Nursing implications	5
	2.3	Fixing of lines	5
	2.4	Placement of infusion lines	6
	2.5	Use of infusion pumps	6
	2.6	Interruption to lines	7
	2.7	Additional notes	8
3.	Prac	ctical Applications	9
	3.1	Insertion of UVC/CVL care bundle 1	0
	3.2	CVL/UVC Line Changes and Maintenance Care Bundle 1	2
	3.3	Additives via CVL / UVC Care Bundle 1	5
	3.4	Emergency Management of CVL Occlusion Care Bundle 1	7
	3.5	Bundle of Care for CVL / Broviac Hickman catheter dressing 1	9
	3.6	Removal of CVL / UVC Care Bundle and disconnecting antibiotic lines 2	2
4.	Evic	lence Base	24
	4.1	Associated documents	:4
	4.2	References 2	24

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021	
Facilitator	Title	Registere	d Nurses N	CU	Department:	NICU		
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING								



1. Overview

1.1 Purpose

To ensure safe and efficient initiation, delivery and ongoing management of neonatal fluid and medications via a neonatal specific central vascular access device (CVAD), and the minimisation of infection.

CVAD in NICU includes umbilical/Broviac and peripherally inserted central catheter.

1.2 Scope

For neonates

1.3 Patient Groups

Neonates and infants in NICU

1.4 Definitions

Aseptic non-touch technique (ANTT)	Aseptic Non-Touch Technique (ANTT) is a technique that maintains asepsis and is non-touch in nature.
	The key parts of any procedure are identified and protected – this includes staff performing effective hand hygiene, instituting a non-touch technique when handling, and wearing the appropriate standard precautions.
	For the purpose of this procedure the word "STERILE" will continue to be used to describe access to the CVAD.
Broviac line	A silastic central line that is tunnelled from the skin of the chest wall into a central vein in the neck and sits just above the heart (unless otherwise specified, care is the same as for Central Venous Line). It is inserted and removed under general anaesthetic.
Bundle of care	Care bundles are groupings of best practice interventions, which individually improve care but when applied together, result in a significantly greater improvement.
Clear fluids	Neonatal Starter/Regular, sterile water, sodium chloride 0.9%, dextrose 10%
CNS	Clinical Nurse Specialist
СРАР	Continuous Positive Airway Pressure
CVAD	Central Venous Access Device
CVL	Central Venous Line (CVAD known as in NICU) is an intravenous catheter placed via a blood vessel into a great vein (in NICU these are most commonly PICC lines)
D10W	Dextrose 10%
ETT	Endotracheal tube

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator	itator Title Registered Nurses NICU				Department:	NICU	
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING							



IA Line tray	Intra-arterial line tray - sterile pack containing instruments required for line insertion
КСІ	Potassium chloride
куо	Abbreviation for "keep vein open" on an infusion pump
Medical staff	In NICU they include Nurse Practitioner Neonatology, Clinical Nurse Specialist, Registrar and Paediatrician.
NaCl	Sodium Chloride
NCV	NICU Advanced Procedure Certificate
NNP	Nurse Practitioner Neonatology
NN Starter/Regular	Specialised neonatal total parenteral nutrition used for preterm infants or term infants unable to tolerate enteral feeds for a prolonged period: Neonatal Starter is electrolyte free and used during first few days following birth. Neonatal Regular contains electrolytes and is used once Neonatal Starter is discontinued.
PICC	Peripherally inserted central catheter
PIV	Peripherally inserted intravenous catheter
Sterile technique	A true sterile technique is not achievable in the NICU environment however the term sterile is used to enforce the importance of maintaining aseptic practice at all times
TPN	Total Parenteral Nutrition
U & E	Commonly used abbreviations for urea and electrolyte testing
Uses of CVL and UVC in NICU	 To facilitate multiple infusions of hypertonic solutions, high dextrose concentrations >12.5% and drugs over an extended period of time To avoid the need for and physiological stress of repeated intravenous cannulation Reduce the risk of extravasation of fluid into the tissues causing necrosis and phlebitis Emergency vascular access for fluid and medication Exchange transfusions
UVC	Intravenous catheter placed via the umbilicus into the inferior vena cava
VТBI	Volume to be infused – pump will alarm once volume has been delivered

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021	
Facilitator	Title	Registere	d Nurses N	CU	Department:	NICU		
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING Page								



2. Clinical Management

2.1 Competency required

• Registered Nurse who has completed orientation and training and achieved a NICU advanced procedure certification – NCV.

NB: A NICU specific advanced medication certification is also required when introducing medications to CVAD lines

• Medical staff - Insertion of lines

2.2 Nursing implications

Preterm infants have an immature system, therefore the nurse acts as the patient advocate. Careful observation and assessment of the infant's tolerance of any procedure must be maintained during any CVAD procedure and the maintenance of sterility must be a priority – particularly if multiple attempts at cannulation occur or when the procedure is prolonged.

To achieve this, use:

- Screen/barrier and "STOP" signs to eliminate unnecessary traffic through the room while line access is in progress
- Limit the number of people at the bedside
- Close doors
- Take care in preparing equipment
- Ensure adequate continuous monitoring of vital signs
- Maintain visualisation of the infant's chest movement, ETT or CPAP prongs and the baby's colour. The infant must be connected to the infant warmer servo probe.

2.3 Fixing of lines

Once x-ray confirms position, lines need to be secured for stability.

CVL – CVL is fixed and secured by medical staff on insertion under sterile conditions, nurse to ensure line is secured and comfortable outside the sterile dressing. Ensure Tegaderm does not overlap when wrapped around a limb as it may interfere with circulation when swelling or weight gain occurs.

UVC – Duoderm is placed on the skin and a bridge made with Sleek in which the tubing is coiled ensuring no tension on the line.

NB: Do not apply the Duoderm bridge for extremely low birth weight babies until they are over a week old to reduce risks of injury to the fragile skin

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021	
Facilitator	Title	Registere	d Nurses N	CU	Department:	NICU		
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING								



2.4 Placement of infusion lines

If multiple infusions are required take special care with placement. Inotropes need to be placed closest to the patient therefore require a dedicated line and filter (**Port3**). If more than one inotrope is used, a double or triple lumen smart site will be necessary. All other medications are to be infused through **Port 2** in combination with lipids, NN Starter/Regular or other maintenance clear fluids to infuse through a dedicated separate line (**Port 1**) to minimise the need to access this fluid.



2.5 Use of infusion pumps

The Alaris signature pump is to be used with clear fluid/TPN/lipid bags. Pump pressure settings must be checked and recorded hourly. Pressure limit should be set at 50mmHg, with a 4 hour VTBI set. In-line burettes to be used on all lines *except* NNStarter and term lipid bags.

When using a burette check fluid bag and burette at commencement of each shift and every time VTBI is reset. <u>VTBI set must be LESS than amount of fluid in</u> <u>burette</u> to prevent burette running dry. Even if no fluid is present in the burette the pump action will draw air from the burette into the infusion line toward the baby causing high risk of air embolus.

The Asena CC infusion pump must be used for delivery of lipids and medications. The pressure alarms must be checked and documented hourly. Due to the very small infusion volumes used in the NICU it is essential that a pump with pressure monitoring be used wherever possible, to promptly alert staff if occlusion should occur.

The GuardrailTM software <u>must</u> be used unless specified by medical staff. If guardrails is not able to be used this must be documented on the General Treatment Sheet to identify that the ml/hour setting is to be used.

It is mandatory for <u>both nurses</u> to set and check the Guardrail[™].

Double pumping – When changing INOTROPE lines on inotrope-dependent infants using smart sites: wherever possible collect extra pumps and once inotrope is drawn up place on new pump and run each infusion through to ensure each drug is equally mixed and primed to the end of outlet. This avoids delays created when medications are running

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021	
Facilitator	Facilitator Title Registered Nurses NICU				Department:	NICU		
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING Pag								



at very low rates. If a baby is on multiple inotropes consider staggering the line changes to avoid major interruption to the delivery of medications.

It is mandatory for both nurses to check:

- Correct infusions/medications in the correct infusion pumps
- Lines from baby to pump to ensure all clamps are open, no kinks or leaks are present
- Lines are correctly labelled for easy identification of the infusions
- Pump is set at the correct delivery rate, with a 4 hourly maximum VTBI set on volumetric pumps only

2.6 Interruption to lines

This greatly increases the risk of sepsis. In order to minimise interruption to CVL/UVC fluids the following protocol will be required:

- a) Every time the CVL/UVC catheter site is accessed for a dressing change, adjustment of line, infusion set change, blood sampling or transfusion of blood product; it must be done in a <u>sterile</u> technique as per steps in the CVL/UVC Line Changes and Maintenance Care Bundle (page 12-16). For emergency access see care bundle (page 17).
- b) All accessing of a BROVIAC line must be done using the NICU SPECIFIC CVL CARE BUNDLES sterile procedure – include blood sampling, transfusion of blood products, administration of medication and line changes.
- c) For an infusion set change, clean the hub, line and the smart site connector lumen with chlorhexidine in alcohol cleansing agent using single swabs generously, <u>clean for 15</u> <u>seconds and wait to allow solution to fully dry</u>. Use a fresh chlorhexidine swab to hold the line/connector.
- d) Use CVL dressing pack sterile drapes and non-touch technique for preparation, priming and connection of infusion set as described below in the Bundle of Care for CVL/UVC maintenance.
- e) Immediately attached to the UVC/CVL catheter will be an Alaris smart site triple lumen extension set. The lumens will be allocated as follows:

Port 1 - Infusion giving set and filter for clear fluids, NN Regular/Starter, dextrose, sterile water, sodium chloride 0.9%, or insulin infusing on Port 1 **will be changed every 72 hours**. If bag runs out prior to 72 hours a full line change will be required. Insulin infusion without a filter – also should be changed at 72 hours. All clear fluid filters and smart sites may stay in situ for 72 hours.

Port 2 – Syringe pump infusion sets, double or triple lumen smart site adaptors as required for delivery of other medications and lipids. Medications and lipids changed 24 hourly – change syringe and extension line only. Lipid filters remain a 24 hourly change.

Port 3 – **Dedicated** inotrope port **or** use for emergency port/lipids/medications/antibiotics if no inotropes in use.

NB: Emergency port selection

The emergency port is an identified spare access port for quick access in emergencies or if a line occlusion requires flushing – usually on Port 3 if no inotropes in use. Either of the

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator	Facilitator Title Registered Nurses NICU			Department:	NICU		
IF THIS D	OCUMENT	IS PRINTI	ED, IT IS V <i>i</i>	OR THE DAY OF	PRINTING	Page 7 of 24	



other ports may have an emergency access port included; select most appropriate port based on what medication is infusing: e.g. avoid using lines where insulin or inotropes are infusing to avoid a bolus being given if the line is flushed.

Label EMERGENCY PORT with a green flag for rapid identification

Port 1 - NNStarter+D10W/Regular/Clear fluids (dedicated port)

Port 2 - Lipids & medications



antibiotics or medication if no inotropes, antibiotic, caffeine

2.7 Additional notes

a) Babies <1000g and a small group of babies weighing >1000g with a CVL, access will have NNStarter fluid commenced as initial TPN. This fluid runs at a maximum of 30ml/kg/day therefore must be accompanied by a bag of D10W with a burette to make up remainder of total daily volume.

Due to high protein concentration no burette or additives are to be infused with NNStarter.

No cuff BPs to be used on the limb with CVL as they apply pressure directly over the vein containing the catheter which may cause compromise to its function.

- b) Burettes used for additives, e.g. NaCI, KCI, may stay in the line for 72 hours. The additives can be topped up as many times as required over the 72 hour period under full sterile conditions.
- c) If for any reason the Port 1 line (apart from the burette) is broken into, including under sterile conditions, all lines on that port must be changed down to the filter (don't need to change the filter)
- d) If antibiotics are being administered via CVL through Port 3, the filter may remain in situ for 72 hours (label with date and time when changed).
- e) Inspect CVL catheter insertion site hourly for signs of soiling, redness, swelling or signs of local infection. Complete and document CVL safety and assessment once per shift. Change dressing only if soiled or lifting. If suspicion of local or systemic infection consider prompt removal of catheter after discussion with consultant in charge.
- f) If the CVL catheter is to remain in situ for antibiotics or any other purpose, use sodium chloride 0.9% or D10W infusion as prescribed at a minimum rate of 1ml/hr through the CVL.

Full line change required after 72 hours using sterile technique. Generally NNRegular or Dextrose 10% solution is for KVO purposes.

g) Maintaining sterility is vital in preventing catheter-related infection and is a two-person procedure at all times. If the line is changed from one site to another or removed and replaced, all fluids, drugs, lines, filters and connections must also be replaced.

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator	Title	Registered	d Nurses NI	CU	Department:	NICU	
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR					OR THE DAY OF I	PRINTING	Page 8 of 24



 h) If blood sampling is from a UVC follow the sampling section of the NICU service specific Umbilical Arterial Catheter guideline, but use the central line <u>sterile technique</u> and 5ml syringes for accessing the catheter.

Lippincott Procedures provides a paediatric procedure that guides the actual sampling technique (Link on p.21)

i) When doing surgical handwashing, the basic principle is to wash hands thoroughly, then wash from a clean area (hand) to a less clean area (arm). A systematic approach to scrub is an efficient way to ensure proper technique.

Refer to Lippincott surgical scrub procedure at: <u>http://procedures.lww.com/lnp/view.do?pld=729670</u>

3. Practical Applications

This part of this document is dedicated to the detailed practical application of the Care Bundles that govern all the six most common central venous/umbilical venous procedures. They are listed as follows:

- 4.1 <u>Insertion of UVC/CVL Care Bundle</u> (P.10)
- 4.2 <u>CVL/UVC Line Changes and Maintenance Care Bundle</u> (P.12)
- 4.3 Additives via CVL/UVC Care Bundle (P. 15)
- 4.4 <u>Emergency Management of CVL Occlusion Care Bundle</u> (P. 17)
- 4.5 <u>CVL/Broviac Hickman Catheter Dressing Care Bundle</u> (P. 19)
- 4.6 Bundle of Care For Removal of CVL/UVC (P. 22)

Sampling from a Broviac Line: <u>http://procedures.lww.com/lnp/view.do?pld=728990</u> Flushing a Broviac Line: <u>http://procedures.lww.com/lnp/view.do?pld=728993</u>

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator	acilitator Title Registered Nurses NICU		Department:	NICU			
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING						Page 9 of 24	



3.1 Insertion of UVC/CVL care bundle

Equipment

- Trolley
- Dr Gown pack x 1
- Masks & Caps x2
- Sterile Gloves
- Sterile drapes
- Neonatal I.A. Line Tray
- U.V.C. Catheter / C.V.L. Catheter
- 3 way Tap x 1
- 5 ml syringe
- 10 ml syringes
- Drawing up needles
- 0.9% sodium chloride
- Cord tie for UVC
- 4.0 Silk for UVC
- Infusion pump &/ syringe pumps
- Aqueous (non-alcohol) chlorhexidine cleansing agent for skin
- Sterile water for skin clean post chlorhexidine
- Chlorhexidine in alcohol cleansing agent for lines & connections
- Omnipaque for CVL
- Sterile rubber tip forceps (for Broviac line)
- Tegaderm/Opsite for C.V.L.
- Screen/ "STOP" sign for doorway

NB: Plan workload to ensure adequate time for full procedure to be carried out, i.e. containment of the infant beneath the sterile drapes, insertion, position check and setting up of lines.

Procedure

Action	Rationale
 Consider analgesia for baby – Dextrose Gel 40% if > 1000g 	To minimise stress of the procedure
 Plan timing: check that there are other staff in the room free to provide care for other infants. Consider the timing of other cares for the infant 	Line changes can be long and complex. Nurses must minimise distractions to avoid errors
3. Ensure access to nursery restricted with screen and "STOP" signs prior to commencing procedure	To reduce risk of contamination of sterile field by traffic through the area
4. Clean trolley with Tuffie wipes and leave to dry	To minimise risk of contamination
 Collect equipment required – do not open until medical staff ready to proceed. 	To minimise exposure of sterile field to environmental contamination
6. Use the large bin for disposal of rubbish	To prevent contamination

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator	acilitator Title Registered Nurses NICU		Department:	NICU			
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING Page 10 c							Page 10 of 24



7 Assist medical staff to down up then prepare IA line	
tray and equipment as required.	
8. Assist with procedure as required	An active infant may require containment
9. Call for x-ray when the insertion is almost completed so the medical staff remains gloved and can give the contrast material immediately preceding chest x-ray. If there is a delay for x-ray, the medical staff will attach the Omnipaque (in a 5mL syringe) to the free end of the three-way tap (as per diagram).	
ONLY Medical staff to give the contrast material NOT the nurse.	Due to potential for adverse reaction to Omnipaque, medical presence is required
OMNIPAQUE 5ml	
BABY with CVL	
BABY with CVL 3-way tap 10. After the x-ray, the fluids can be connected when the position of UVC/CVL is confirmed.	

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator	Title	Registered Nurses NICU		Department:	NICU		
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING						PRINTING	Page 11 of 24



3.2 CVL/UVC Line Changes and Maintenance Care Bundle

Line Change - UVC/CVL/Broviac line

Indications

- Every 72 hours lines, fluids, primary smart site triple lumen adapter and filter are changed on clear fluids.
- Every 24 hours lipids and all other medication infusions and extension lines are changed. Filters for medications remain for 72 hours; lipid filters change with 24 hour line change.
- D10W bags used for making up CVL medications must be labelled "CVL" and remain refrigerated, and once opened may be used for 8 hours then discarded.

NB: The fewer breaks into the line the less chance for infection.

Equipment

- Trolley
- Dressing pack
- CVL gown pack
- Caps and masks x 2
- Sterile gloves
- UVC only sterile forceps
- Cleansing agent chlorhexidine in alcohol
- Appropriate number of spare pumps for double pumping if required
- IV Solution and/or drugs as prescribed
- IV giving set and smart site double / triple lumen adapters as required
- Filters for clear fluids and lipid
- Syringe pump extension sets
- Extension set luer lock
- Bag access device if required
- Drawing up needles
- Filter needles
- Fluid balance sheet
- Line change recording sheet
- Treatment / medication sheet
- Screen/"STOP" sign for doorway

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator	Title	Registered Nurses NICU		Department:	NICU		
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY F					OR THE DAY OF	PRINTING	Page 12 of 24



Procedure: Line Change

Act	ion	Rationale		
1.	Perform hand hygiene	To minimise risk of infection		
2.	Place screen across nursery entrance as required and "STOP" signs for doorway	To minimise environmental contamination of sterile field		
3.	Collect trolley cleaned with Tuffie wipes and allow to dry	To minimise risk of contamination.		
4.	Collect required equipment as above and arrange on trolley extension away from sterile field	To minimise contamination when pack and equipment opened		
5.	Use the large bin for disposal of rubbish	To prevent contamination		
6.	Two nurses throughout procedure: one to be identified as the "sterile nurse" and one is the assistant	To facilitate sterile technique throughout		
7.	 Checking prior to procedure (i) Check patient's identity. (ii) Ensure I.D. label matches patient's I.D. sticker on treatment sheet. (iii) Check fluids correspond with fluids prescribed on treatment sheet. (iv) Two nurses should check independently the following: Check drug doses and calculations with protocols and computer/calculator. (v) Two nurses to set up the guardrails 	To ensure correct patient and comply with Waikato Hospital Medicine Management Policy		
8.	Put on masks and caps	To avoid airborne contamination		
9.	Perform hand hygiene	To minimise risk of infection		
10.	Assistant to open sterile CVL gown pack – sterile nurse to dry hands with sterile towels from gown pack; then sterile nurse put on gown and gloves in a sterile manner. Assistant to tie gown using both neck and waist ties	To minimise risk of contamination		

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator	Title	Registered Nurses NICU		Department:	NICU		
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING							Page 13 of 24



11. Assista allowin (i) or	ant to open dressing pack and equipment one by one g sterile nurse to: pen dressing pack onto sterile drape	To maintain aseptic environment and ensure maximum area for sterile field
(ii) ar	range equipment onto dressing pack.	
12. Assista	ant to open chlorhexidine swabs using non-touch	Pouching the swab packet allows swab
technic	que and 'pouch' the swab packet – sterile nurse to	to be removed without contamination on
take sv	vabs with forceps	edges
13. Assista tab.	ant will hold bag of prescribed fluids and open blue	To maintain line and fluid sterility
Sterile	nurse to use chlorhexidine in alcohol cleansing agent	Chlorhexidine in alcohol needs to dry to
to clea	n connectors and lines: using single swab wipe area	prevent contamination of fluid and
thorou	ghly for 15 seconds and wait to allow solution to fully	ensure maximum antimicrobial effect
ary. Ir	ien use a fresh chlornexidine swab to hold the	
cloar fi	Iter to and of giving set	
	ter to end of giving set.	
14. Prime	tubing, filter and ports slowly, checking tubing is free	To avoid air embolus and minimise
of air b	ubbles. Ensure connections are secure and all	potential for bacterial growth on line
surface	e of giving set and inner section of connector ports	
remain	free of excess lipid or dextrose solution.	
Flush	emergency port with sodium chloride 0.9%.	
15. When	I.V. tubing has been primed, leave same on sterile	To maintain line sterility of all line
field. I	Protect all key parts as per ANTT guideline.	connections
Drow	in modioations and prime into amort site parts refer	
Diaw C	of this document for line set up diagram and double	of modications in extensions and avoid
numnir	or this document for line set up diagram and double	delays in drug administration
pumpi		
16. Once a	all fluids are connected and infusing, sterile nurse to	To remove fluid residue from outside of
wipe a	I ports with chlorhexidine in alcohol swabs	line (often dextrose) and reduce risk of
		microbial growth
17. Both st	aff together check all clamps are open and infusions	Ensure no lines trapped in door or
running	g at correct rate. Check lines and ports visible and	clamped which will delay medication
close ii	ncubator door.	fluid delivery
18. Sterile	nurse to disrobe and both nurses to dispose of used	
equipm	nent in appropriate receptacle according to walkato	
рнв р	olicies	
19 Docum	pent fluids and line / filter change on recording sheet	To identify change and calculate when
and me	edications on NICU drug chart.	next due.
Label r	nedication lines and infusion lines.	
20. Perform	n hand hygiene.	To minimise infection risk.
21. All infa	nts with CVL must have:	Early detection of complications enables
•	hourly fluid balance and line pressure monitoring,	early interventions
•	3-4 hourly vital signs monitoring,	
•	2-4 hourly site observation	
•	3-4 hourly full inspection of insertion site, dressing	
	and surrounding areas, e.g. limbs, during cares.	

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator Title		Registered Nurses NICU		Department:	NICU		
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING Page 14 of							Page 14 of 24



3.3 Additives via CVL / UVC Care Bundle

Indications

- Infants requiring electrolyte supplementation will be identified from daily U&E results. Burettes may stay in line for 72 hours and be accessed for top-ups under full sterile conditions.
- · Infants requiring medication, e.g. antibiotic, caffeine, with no other IV access

Equipment

- Trolley
- Masks and caps x2
- Sterile gloves
- CVL gown pack
- Dressing pack
- Syringes and drawing up needles as needed
- Asena CC extension set/s
- Additives and diluents (electrolytes or antibiotics)
- · Chlorhexidine in alcohol cleansing agent
- Sodium chloride 0.9% for flushes
- Screen/"STOP" sign for doorway

Procedure: two nurses procedure

Act	tion	Rationale
1.	Perform hand hygiene.	Minimise risk of infection
2.	Place screen and "STOP" sign across doorway	To restrict access to nursery during sterile procedure
3.	Clean trolley with Tuffie wipes and allow to dry	To prevent contamination of serile equipment
4.	 Collect equipment, additives/antibiotics to be administered. Two nurses to check : a. Medications as per Waikato NICU drug manual or computer programme. b. Correct patient & prescriptions as per Waikato DHB policy. 	Waikato DHB medication safety policy requires two nurses to check all medications
5.	Prepare UVC/ CVL antibiotics/additives using sterile technique, remaining medication may be offered to babies with peripheral IV.	To maintain asepsis of all devices fluids accessing the central line catheter and minimise risk of infection
6.	Put on masks and caps and perform hand hygiene.	To minimise risks of airborne contamination and infection
7.	Assistant to open CVL gown pack and sterile gloves and assist sterile nurse to put on gown and gloves.	To minimise risk of contamination
8.	 Drawing up medication Medications / additives to be drawn up aseptically using ANTT principles. Assistant ensures solution mixed following addition of medication. 	To minimise risk of contamination. Adequate mixing ensures accurate dose administration

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator	Title	Registere	d Nurses N	ICU	Department:	NICU	
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FO					OR THE DAY OF	PRINTING	Page 15 of 24



 Bungs and ampoule necks to be cleaned and opened by assistant using alcohol-chlorhexidine swabs. Clean the bungs with chlorhexidine swabs before accessing the vial to draw up the medication. Assistant will hold up C.V.L. / U.V.C tubing attached to baby. Sterile nurse will: Grasp line with chlorhexidine swab and clean luer port & tubing with cleansing agent and allow to dry. Place sterile drape under connection and place cleaned connection not drape lue to be clamped off to fluids. For administration of additives to burette: Assistant to fill burette to 100ms with infusate as prescribed and hold for sterile nurse to clean access port with sterile gauze, add electrolytes and genty mix. Do not allow air intel valve at top of burette to become wet whem mixing. Clean port on burete means accessing in exonine diging set at filter and run 25mil fluid through line - reconnect and assistant <i>restart fluid at prescribed rate</i>. Both nurses check connections and rate - ensure air inel valve is unclamped. Attach red Medication added label to burette. Web S ml syringe for all flushes and meds to ensure even pressure. If the medication is a small amount, transfir it to 37m syring, dilute if needed, then administr (use 10mi syring, dilute if needed, then administer (use 10mi syring, dilute if needed, then	1		
 Clean the bungs with chlorhexidine swabs before accessing the vial to draw up the medication. Assistant will hold up C.V.L. / U.V.C tubing attached to baby. Sterile nurse will: Grasp line with chlorhexidine swab and clean luer port 8 tubing with cleansing agent and allow to dry. Place sterile drape under connection and place cleaned connection onto drape Line to be clamped off to fluids. To avoid accidental bolus of drug or air to enter port. To avoid accidental bolus of drug or air to enter port. To avoid accidental bolus of drug or air to enter port. To avoid accidental bolus of drug or air to enter port. To avoid accidental bolus of drug or air to enter port. To avoid accidental bolus of drug or air to enter port. To avoid accidental bolus of drug or air to enter port. To avoid accidental bolus of drug or air to enter port. To avoid accidental bolus of drug or air to enter port. To avoid accidental bolus of drug or air to enter port. To avoid accidental bolus of drug or air to enter port. To avoid accidental bolus of drug or air to enter port. To avoid accidental bolus of drug or air to enter port. To avoid accidental bolus of drug or air to enter port. Grasp access port with sterile gauze, add electrolytes and gently mix. Do not aliow air inter valve at top of burette. Grasp access port with sterile gauze, add electrolytes and gently mix. Do not aliow air inter valve at top of burette. Both nurses check connections and rate ensure even pressure. If the medication is a smail amount, transfer it to a 5ml syringe, dilute in needication sis a smail amount, transfer it to a 5ml syringe, dilute in needication sis a smail amount, transfer it to a 5ml syringe, dilute in eaded, label to bourte. If UVC /CVL is lushed thoroughly after medications usin a test? I mid sodium chloride 0.9%.<!--</td--><td></td><td> Bungs and ampoule necks to be cleaned and opened by assistant using alcohol- chlorhexidine swabs. </td><td>To minimise risk of key part contamination.</td>		 Bungs and ampoule necks to be cleaned and opened by assistant using alcohol- chlorhexidine swabs. 	To minimise risk of key part contamination.
 Assistant will hold up C.V.L. / U.V.C tubing attached to baby. Sterile nurse will: Grasp line with chlorhexidine swab and clean luer port & tubing with cleansing agent and allow to dry Place sterile drape under connection and place cleaned connection onto drape Line to be clamped off to fluids. To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port For administration of additives to burette: Grasp access port with chlorhexidine – allow to dry. Grasp access port with sterile gauze, add electrolytes and genty mix. Do not allow air inlet valve at top of burette to become wet when mixing. Clean port on burette If a new prescription of electrolytes, disconnect giving set at filter and run 25/nl fluid through line – reconnect and assistrant restart fluid at prescribed rate. Both nurses check connections and rate ensure air nilet valve is unclamped. Attach red Medication added label to burette. If Ser administration of antibiotics: Use 5 ml syringe for all flushes and medis to ensure aver pressure. If the medication is a small amount, transfer it to a 5 nl syringe, dlute if needod, then administer (use 10ml syringe for Broviac). If U/C /C/L is neonottal solution chloride 0.9%. Open port again to fluids, both nurses to check and recommence infusion as prescribed. Document antibiotics/additives on NICU Drug Administration Record Sheet. Dispose of used equipment, then re-clean trolley with Tuffie wipe, and perform hand hygiene. Use of used equipment, then re-clean trolley administration a derigo ment, then re-cleant trolley requirement Dispose of used equipment, then re-cleant rolley 		 Clean the bungs with chlorhexidine swabs before accessing the vial to draw up the medication. 	
 Grasp line with chlorhexidine swab and clean luer port & tubing with cleansing agent and allow to dry Place sterile drape under connection and place cleaned connection ont drape Line to be clamped off to fluids. To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter To avoid ac	9.	Assistant will hold up C.V.L. / U.V.C tubing attached to baby.	To maintain a sterile working field and protect key parts of CVL/UVC from contamination
 Place sterile drape under connection and place cleaned connection onto drape Line to be clamped off to fluids. To avoid accidental bolus of drug or air to enter port For administration of additives to burette: Assistant to fill burette to 100mls with infusate as prescribed and hold for sterile nurse to clean access port with chlorhexidine – allow to dry. Grasp access port with sterile gauze, add electrolytes and gently mix. Do not allow air inlet valve at top of burette to become wet when mixing. Clean port on burette If a new prescription of electrolytes, disconnect giving set at filter and run 25ml fluid through line – reconnect and assistant restart fluid at prescribed rate. Both nurses check connections and rate – ensure air inlet valve is unclamped. Attach red Medication added label to burette. For administration of antibiotics: Use of smaller syringe may create high pressures anall amount, transfer it to 35ml syringe, dilute it needed, then administer (use 10ml syringe for Broviac). If UVC / CVL is flushed thoroughly after medications using at least 2 ml of sodium chloride 0.9%. Open port ang in to fluids, both nurses to check and recommence influsion as prescribed. Wipe down port and line again with cleansing agent. Document antibiotics/additives on NICU Drug Administration Record Sheet. Hoispose of used equipment, then re-clean trolley with Tuffe wipe, and perform hand hygiene. 		 Grasp line with chlorhexidine swab and clean luer port & tubing with cleansing agent and allow to dry 	
 Line to be clamped off to fluids. To avoid accidental bolus of drug or air to enter port To avoid accidental bolus of drug or air to enter port For administration of additives to burette: Assistant to fill burette to 100mls with infusate as prescribed and hold for sterile nurse to clean access port with chlorhexidine – allow to dry. Grasp access port with sterile gauze, add electrolytes and genty mix. Do not allow air inlet valve at top of burette to become wet when mixing. Clean port on burette If a new prescription of electrolytes, disconnect giving set at filter and run 25ml fluid through line – reconnect and assistant restart fluid at prescribed rate. Both nurses check connections and rate – ensure air inlet valve is unclamped. Attach red Medication added label to burette. 11. For administration of antibiotics: Use 5 ml syringe for all flushes and meds to ensure even pressure. If the medication is a small amount, transfer it to a 5ml syringe, dilute if needed, then administer (use 10ml syringe for Broviac). If UVC / CVL has neonatal solution and/or lipid, ensure adequate amount of flush is used to clear extension line of solution. Administer antibiotics/additives. Ensure UVC/CVL is flushed thoroughly after medications ugat least 2 ml of sodium chloride 0.9%. Open port again to fluids, both nurses to check and recommence infusion as prescribed. Wipe down port and line again with cleansing agent. Document antibiotics/additives on NICU Drug Administration Record Sheet. To remove fluid residue from outside of line (often dextrose) and reduce microbial growth 13. Document antibiotics/additives on NICU Drug Administration Record Sheet. To grow of use dequipment, then re-clean trolley with Tuffe wipe, and perform hand hygiene. 		Place sterile drape under connection and	
 10. For administration of additives to burette: Assistant to fill burette to 100mls with infusate as prescribed and hold for sterile nurse to remain sterile at all time when accessing existing burette. Grasp access port with chlorhexidine – allow to dry. Grasp access port with sterile gauze, add electrolytes and genty mix. Do not allow air inlet valve at top of burette to become wet when mixing. Clean port on burette If a new prescription of electrolytes, disconnect giving set at filter and run 25ml fluid through line – reconnect and assistant restart fluid at prescribed rate. Both nurses check connections and rate – ensure air inlet valve is unclamped. Attach red Medication added label to burette. 11. For administration of antibiotics: UVC / CVL has neonatal solution and/or lipid, ensure adequate amount of flush is used to clear extension line of solution. Administer antibiotics/additives. Ensure UVC/CVL is flushed throoughly after medications gat east 2 ml of sodium chloride 0.9%. 12. Open port again to fluids, both nurses to check and recommence infusion as prescribed. 13. Document antibiotics/additives on NICU Drug Administration Record Sheet. 14. Dispose of used equipment, then re-clean trolley with Tuffie wipe, and perform hand hygiene. 16. Winimister and biotics/additives on NICU Drug with Tuffie wipe, and perform hand hygiene. 16. Winimistration Record Sheet. 17. Minimise risk of injury and infection 18. Document antibiotics/additives on NICU Drug with Tuffie wipe, and perform hand hygiene. 19. Minimise risk of injury and infection 10. Minimise risk of injury and infection 10. Minimise risk of injury and infection 11. For administration Record Sheet. 13. Document antibiotics/additives on NICU Drug Administration Record Sheet. 14. Dispose of used equipment, then re-clean trolley with Tuffie wipe, and		 Line to be clamped off to fluids. 	To avoid accidental bolus of drug or air to enter port
 Assistant to fill burette to 100mls with infusate as prescribed and hold for sterile nurse to clean access port with sterile gauze, add electrolytes and genty mix. Grasp access port with sterile gauze, add electrolytes and genty mix. Do not allow air inlet valve at top of burette to become wet when mixing. Clean port on burette of electrolytes, disconnect giving set at filter and run 25ml fluid through line – reconnect and assistant restart fluid at prescribed rate. Both nurses check connections and rate – ensure air inlet valve is unclamped. Attach red Medication added label to burette. 11. For administration of antibiotics: Use 5 ml syringe for all flushes and meds to ensure even pressure. If the medication is a small amount, transfer it to a 5ml syringe, dilute if needed, then administer (use 10ml syringe for Broviac). If UVC / CVL has neonatal solution and/or lipid, ensure attratibiotics/additives. Ensure UVC/CVL is flushed thoroughly after medications using at least 2 ml of sodium choloride 0.9%. 12. Open port again to fluids, both nurses to check and recommence infusion as prescribed. Wipe down port and line again with cleansing agent. 13. Document antibiotics/additives on NICU Drug Administration Record Sheet. 	10	For administration of additives to burette:	
 Grasp access port with sterile gauze, add electrolytes and gently mix. Do not allow air inlet valve at top of burette to become wet when mixing. Clean port on burette If a new prescription of electrolytes, disconnect giving set at filter and run 25ml fluid through line – reconnect and assistant restart fluid at prescribed rate. Both nurses check connections and rate – ensure air inlet valve is unclamped. Attach red Medication added label to burette. 11. For administration of antibiotics: Use 5 ml syringe for all flushes and meds to ensure even pressure. If the medication is a small amount, transfer it to a 5ml syringe, dilute if needed, then administer (use 10ml syringe for Broviac). If UVC / CVL has neonatal solution and/or lipid, ensure adequate amount of flush is used to clear extension line of solution. Administer antibiotics/additives. Ensure UVC/CVL is flushed throroughly after medications using at least 2 ml of sodium chloride 0.9%. Qopen port again to fluids, both nurses to check and recommence infusion as prescribed. Wipe down port and line again with cleansing agent. Document antibiotics/additives on NICU Drug Administration Record Sheet. Minimise risk of injury and infection 		 Assistant to fill burette to 100mls with infusate as prescribed and hold for sterile nurse to clean access port with chlorhexidine – allow to dry. 	Sterile nurse to remain sterile at all time when accessing existing burette.
 Do not allow air inlet valve at top of burette to become wet when mixing. Clean port on burette If air inlet becomes wet, air is unable to enter burette to replace infused fluid – negative pressure causes burette to collapse potentially interfering with delivery and line patency. Both nurses check connections and rate – ensure air inlet valve is unclamped. Attach red Medication added label to burette. 11. For administration of antibiotics: Use 5 ml syringe for all flushes and meds to ensure even pressure. If the medication is a small amount, transfer it to a 5ml syringe, dilute if needed, then administer (use 10ml syringe for Broviac). If UVC / CVL has neonatal solution and/or lipid, ensure adequate amount of flush is used to clear extension line of solution. Administer antibiotics/additives. Ensure UVC/CVL is flushed thoroughly after medications as prescribed. Wipe down port and line again with cleansing agent. 13. Document antibiotics/additives on NICU Drug Administration Record Sheet. 14. Dispose of used equipment, then re-clean trolley with Tuffie wipe, and perform hand hygiene. 		Grasp access port with sterile gauze, add electrolytes and gently mix	
 Clean port on burette If a new prescription of electrolytes, disconnect giving set at filter and run 25ml fluid through line – reconnect and assistant restart fluid at prescribed rate. Both nurses check connections and rate – ensure air inlet valve is unclamped. Attach red Medication added label to burette. 11. For administration of antibiotics: Use 5 ml syringe for all flushes and meds to ensure even pressure. If the medication is a small amount, transfer it to a 5ml syringe, dilute if needed, then administer (use 10ml syringe for Broviac). If UVC / CVL has neonatal solution and/or lipid, ensure attibiotics/additives. Ensure UVC/CVL is flushed thoroughly after medications using at least 2 ml of sodium chloride 0.9%. 12. Open port again to fluids, both nurses to check and recommence infusion as prescribed. Wipe down port and line again with cleansing agent. 13. Document antibiotics/additives on NICU Drug Administration Record Sheet. 14. Dispose of used equipment, then re-clean trolley with Tuffie wipe, and perform hand hygiene. 		 Do not allow air inlet valve at top of burette to become wet when mixing. 	If air inlet becomes wet, air is unable to enter burette to replace infused fluid – negative pressure
 disconnect giving set at filter and run 25ml fluid through line – reconnect and assistant restart fluid at prescribed rate. Both nurses check connections and rate – ensure air inlet valve is unclamped. Attach red Medication added label to burette. 11. For administration of antibiotics: Use 5 ml syringe for all flushes and meds to ensure even pressure. If the medication is a small amount, transfer it to a 5ml syringe, dilute if needed, then administer (use 10ml syringe for Broviac). If UVC / CVL has neonatal solution and/or lipid, ensure attibiotics/additives. Ensure UVC/CVL is flushed thoroughly after medications using at least 2 ml of solution. Administer antibiotics/additives on NICU Drug Administration Record Sheet. 12. Document antibiotics/additives on NICU Drug Administration Record Sheet. 13. Document antibiotics/additives on NICU Drug with Tuffie wipe, and perform hand hygiene. 		 Clean port on burette If a new prescription of electrolytes 	causes burette to collapse potentially interfering with delivery and line patency.
 fluid through line – reconnect and assistant restart fluid at prescribed rate. Both nurses check connections and rate – ensure air inlet valve is unclamped. Attach red Medication added label to burette. 11. For administration of antibiotics: Use 5 ml syringe for all flushes and meds to ensure even pressure. If the medication is a small amount, transfer it to a 5ml syringe, dilute if needed, then administer (use 10ml syringe for Broviac). If UVC / CVL has neonatal solution and/or lipid, ensure adequate amount of flush is used to clear extension line of solution. Administer antibiotics/additives. Ensure UVC/CVL is flushed thoroughly after medication using at least 2 ml of sodium chloride 0.9%. 12. Open port again to fluids, both nurses to check and recommence infusion as prescribed. Wipe down port and line again with cleansing agent. 13. Document antibiotics/additives on NICU Drug Administration Record Sheet. 14. Dispose of used equipment, then re-clean trolley with Tuffie wipe, and perform hand hygiene. 		disconnect giving set at filter and run 25ml	Ensures line is primed with fluid with new
 Bost reaining of the track of trac		 fluid through line – reconnect and assistant restart fluid at prescribed rate. Both nurses check connections and rate – 	prescription and thus no delay in medication reaching baby.
 11. For administration of antibiotics: Use 5 ml syringe for all flushes and meds to ensure even pressure. If the medication is a small amount, transfer it to a 5ml syringe, dilute if needed, then administer (use 10ml syringe for Broviac). If UVC / CVL has neonatal solution and/or lipid, ensure adequate amount of flush is used to clear extension line of solution. Administer antibiotics/additives. Ensure UVC/CVL is flushed thoroughly after medications using at least 2 ml of sodium chloride 0.9%. 12. Open port again to fluids, both nurses to check and recommence infusion as prescribed. Wipe down port and line again with cleansing agent. 13. Document antibiotics/additives on NICU Drug Administration Record Sheet. 14. Dispose of used equipment, then re-clean trolley with Tuffie wipe, and perform hand hygiene. 15. Use of smaller syringes may create high pressures and rupture catheter Use of smaller syringes may create high pressures and rupture catheter Use of smaller syringes may create high pressures and rupture catheter Use of smaller syringes may create high pressures and rupture catheter Use of smaller syringes may create high pressures and rupture catheter Use of smaller syringes may create high pressures and rupture catheter Use of smaller syringes may create high pressures and rupture catheter Use of smaller syringes may create high pressures and rupture catheter Use of smaller syringes may create high pressures and rupture catheter Use of smaller syringes may create high pressures and rupture catheter Minimise risk of injury and infection 		ensure air inlet valve is unclamped.Attach red Medication added label to burette.	Medication safety and WDHB policy.
 Use 5 ml syringe for all flushes and meds to ensure even pressure. <i>If the medication is a small amount, transfer it to a 5ml syringe, dilute if needed, then administer (use 10ml syringe for Broviac).</i> If UVC / CVL has neonatal solution and/or lipid, ensure adequate amount of flush is used to clear extension line of solution. Administer antibiotics/additives. Ensure UVC/CVL is flushed thoroughly after medications using at least 2 ml of sodium chloride 0.9%. Open port again to fluids, both nurses to check and recommence infusion as prescribed. Wipe down port and line again with cleansing agent. Document antibiotics/additives on NICU Drug Administration Record Sheet. Dispose of used equipment, then re-clean trolley with Tuffie wipe, and perform hand hygiene. 	11	For administration of antibiotics:	
 If UVC / CVL has neonatal solution and/or lipid, ensure adequate amount of flush is used to clear extension line of solution. Administer antibiotics/additives. Ensure UVC/CVL is flushed thoroughly after medications using at least 2 ml of sodium chloride 0.9%. Open port again to fluids, both nurses to check and recommence infusion as prescribed. Wipe down port and line again with cleansing agent. Document antibiotics/additives on NICU Drug Administration Record Sheet. Most of the medications are incompatible with TPN fluids or other medications 		 Use 5 ml syringe for all flushes and meds to ensure even pressure. If the medication is a small amount, transfer it to a 5ml syringe, dilute if needed, then administer (use 10ml syringe for Broviac) 	Use of smaller syringes may create high pressures and rupture catheter
 Administer antibiotics/additives. Ensure UVC/CVL is flushed thoroughly after medications using at least 2 ml of sodium chloride 0.9%. 12. Open port again to fluids, both nurses to check and recommence infusion as prescribed. Wipe down port and line again with cleansing agent. 13. Document antibiotics/additives on NICU Drug Administration Record Sheet. 14. Dispose of used equipment, then re-clean trolley with Tuffie wipe, and perform hand hygiene. 		 If UVC / CVL has neonatal solution and/or lipid, ensure adequate amount of flush is used to clear extension line of solution. 	Most of the medications are incompatible with TPN fluids or other medications
 12. Open port again to fluids, both nurses to check and recommence infusion as prescribed. Wipe down port and line again with cleansing agent. 13. Document antibiotics/additives on NICU Drug Administration Record Sheet. 14. Dispose of used equipment, then re-clean trolley with Tuffie wipe, and perform hand hygiene. Ensure correct delivery of prescribed fluids To remove fluid residue from outside of line (often dextrose) and reduce microbial growth Waikato DHB medicine management policy requirement 		 Administer antibiotics/additives. Ensure UVC/CVL is flushed thoroughly after medications using at least 2 ml of sodium chloride 0.9%. 	
Wipe down port and line again with cleansing agent. To remove fluid residue from outside of line (often dextrose) and reduce microbial growth 13. Document antibiotics/additives on NICU Drug Administration Record Sheet. Waikato DHB medicine management policy requirement 14. Dispose of used equipment, then re-clean trolley with Tuffie wipe, and perform hand hygiene. Minimise risk of injury and infection	12.	Open port again to fluids, both nurses to check	Ensure correct delivery of prescribed fluids
13. Document antibiotics/additives on NICU Drug Administration Record Sheet. Waikato DHB medicine management policy requirement 14. Dispose of used equipment, then re-clean trolley with Tuffie wipe, and perform hand hygiene. Minimise risk of injury and infection		Wipe down port and line again with cleansing agent.	To remove fluid residue from outside of line (often dextrose) and reduce microbial growth
14. Dispose of used equipment, then re-clean trolley with Tuffie wipe, and perform hand hygiene.	13.	Document antibiotics/additives on NICU Drug Administration Record Sheet.	Waikato DHB medicine management policy requirement
	14.	Dispose of used equipment, then re-clean trolley with Tuffie wipe, and perform hand hygiene.	Minimise risk of injury and infection

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator	Title	Registere	d Nurses N	ICU	Department:	NICU	
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING Page 16 of						Page 16 of 24	





3.4 Emergency Management of CVL Occlusion Care Bundle

Indications

- Air detected in the line
- Occlusion alarm
- Fluid bag or burette running out unexpectedly
- Any situation where forward flow of fluid is halted more than momentarily.

Equipment

- Emergency access port. This is the triple lumen port with green flag, attached to the CVL or UVC.
- Dressing pack
- Masks & caps
- Sterile gloves
- Sterile gown pack (if time allows)
- 5 ml syringes (+ drawing up needle) or 10ml syringes for Broviac line
- Sodium chloride 0.9% ampoule
- Chlorhexidine in alcohol cleansing agent

Procedure to be carried out promptly by experienced senior nurse with advanced certification, Co-ordinator/ACNM or medical staff. If in doubt, call for assistance.

Procedure

Action	Rationale
1. Check that no mechanical occlusions interfering with flow, e.g. limb position, line kinked in door, clamp not opened etc.	May avoid unnecessary access to line
2. Prompt attention to alarm is essential.	To initiate prompt action to prevent line blockage.
Call ACNM/Coordinator/medical staff to baby's bedside urgently.	Small bore lines in small vessels potentially occlude quickly.
3. Clean trolley with Tuffie wipes and collect equipment.	
Due to potential urgency, this procedure may not be performed under optimal sterile conditions – consider vancomycin administration and line change following clearance.	
4. Perform hand hygiene	To minimise risk of infection
5. Use sterile technique as per line maintenance bundle and draw up 2 ml of sodium chloride 0.9% into a 5 ml or 10ml syringe	5 m or 10ml syringe generates less pressure, thereby decreasing risk of dislodging clots that may have formed.

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator	Title	Registere	d Nurses N	ICU	Department:	NICU	
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE					OR THE DAY OF	PRINTING	Page 17 of 24





 6. Attach the filled syringe to the emergency port. If Port 3 is in use with inotropes, access Port 1 via green flagged lumen remember lines may need to be changed again after access 	
Up to 2ml of sodium chloride 0.9% should be flushed gently through the line using a 5ml/10ml syringe.	Line is small bore; excess pressure should not be applied.
 This procedure should only take a minute or two, and should be instituted before other measures are taken, e.g. to remove air from lines or change lines etc. 	To try and avoid blood flow back into the line and hence clotting in the line.
8. Dispose of sharps and used equipment in designated receptacle, and re-clean trolley with Tuffie wipe.	To avoid needle stick injury and maintain environmental hygiene
9. Document procedure in clinical notes	

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator	Title	Registere	d Nurses N	CU	Department:	NICU	
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FO					OR THE DAY OF I	PRINTING	Page 18 of 24



3.5 Bundle of Care for CVL / Broviac Hickman catheter dressing

- CVL dressing is the responsibility of the medical team.
- Broviac dressings may be changed by senior nurses competent with this procedure.
- Two-person procedure
- Check with medical staff prior to starting to verify standard dressing change remains the appropriate choice.

Indications

Correct dressing management is critical to preventing infection. The dressing protects the insertion site and cannulated vessel from trauma and keeps the site clean and dry.

- CVL dressing to be changed PRN only or earlier if any signs of soiling, kinking or dressing lifting etc.
- Broviac dressing to be changed every 7 days or earlier if any signs of soiling, kinking or dressing lifting etc.

Equipment

- Trolley
- CVL gown pack Spare sleek dressing tape
- Masks and caps x 2
- Sterile gloves
- Chlorhexidine in alcohol cleansing agent for line
- Aqueous (non-alcohol) Chlorhexidine cleansing agent for skin
- Sodium chloride 0.9%
- Cavilon[™] sticks
- Sterile jumbo matchstick swabs
- Sterile gauze
- Sterile scissors
- Sterile Steri-strips
- Transparent dressing e.g. Tegaderm/Opsite, IV3000 for Broviac

Procedure: Change CVL dressing

Act	ion					Ra	ationale		
1.	 Inspect insertion site 2-4 hourly and during cares for signs of infection/infiltration, i.e. redness, swelling, tenderness, discharge or lifting of dressing 				 Early detection of complications. A swollen limb (or body part) near CVL insertion may indicate: 1. Displacement or tissue of CVL 2. Constriction due to tight dressing and/or tapes. 				
2.	 2. Check that transparent dressing is completely sealed, free from drainage and non-restrictive. If so <u>leave</u> dressing unchanged. Dressings change is not routing. 					Changing insertion site dressing may introduce bacteria into catheter and may inadvertently alter the position of the catheter tip.			
 Dressings change is <u>not</u> routine Evaluate appearance of catheter through insertion site transparent dressing. Observe that catheter is not stretched or pulled 					through	In a. b. c.	dications for cha Partially lifted Evidence of leal Impaired venous distal to site	anging dressing cage around inse s return and/or ti	g: ertion site ssue oedema
Doc	D:	4936	Version:	05	Issue Date	ə:	28 March 2018	Review Date:	28 March 2021
Facilitator Title Registered Nurses NICU				Department:	NICU				
IF T	IF THIS DOCUMENT IS PRINTED. IT IS VALID ONLY					' FC	OR THE DAY OF I	PRINTING	Page 19 of 24



	tout at its insertion into hub and that tong is not	d Destriction of sireulation and/or mayoment
	applied too tightly.	Catheter is very fragile and may tear if pulled.
3.	Proceed with preparations as per Bundle of Care 3 – CVL/UVC Line Change and Maintenance	Maintain sterile principles to minimise contamination of line, insertion site or damage to catheter
4.	Assistant to stabilise the CVL hub and loosen the dressing toward the insertion site, avoiding tension on the catheter. Stretching the dressing can assist.	Dressings can be adhered to catheter great care is needed not to cause catheter migration – easier for assistant to manage.
5.	Medical staff to remove loosen old dressing carefully using forceps and discard into rubbish receptacle	Maintain sterile field and avoid contamination
6.	Inspect the insertion site for signs of infection/infiltration i.e. redness, swelling, tenderness or discharge.	Identification of complications
7.	If discharge present, clean with sodium chloride 0.9%, express any pus and take a swab.	To reduce skin flora present allowing laboratory to identify microorganisms in swab specimen
8.	 (a) Clean skin insertion site once with aqueous (non-alcohol) chlorhexidine cleansing agent and allow to dry (b) Clean catheter/tubing and hub with Chlorhexidine in alcohol from beginning at the insertion site and clean upward away from insertion site to catheter connection, taking special care not to pull on tubing. Allow solution to dry. Gently coil the excess exposed silastic tubing and tape to skin with steri-strip (if not already done). Place small piece of sterile duoderm on skin under blue hub (to protect skin) Place transparent dressing over insertion site and hub – ensuring no kinks in line, if needed cover with a 2nd transparent dressing to ensure all exposed line is protected. 	To reduce surface debris and cleanse tubing, thereby reducing the risk of infection under new dressing To reduce skin flora present on catheter and around connection. The transparent dressing allows easy visualisation of the site and is changed only if it is no longer adherent.
8.	Document condition of insertion site and dressing change in clinical notes.	
9.	Dispose of sharps and rubbish in designated receptacle, and clean trolley with Tuffie wipes.	According to Waikato DHB procedures

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator	Title	Registere	d Nurses N	ICU	Department:	NICU	
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING Page 20 of 2						Page 20 of 24	



Procedure: Change Broviac Dressing

Action	Rationale
1. This is a sterile procedure, follow Bundle of Care	
3:	
Sterile nurse/medical staff to assemble CVL	
gown tray, chlorhexidine cleansing agents,	
standard) jumbo swabs and Cavilon TM wand	
Standard), jumbo swabs and Cavilon wand.	
 Cut sleek strips from IV3000 standard 	
dressing in half with sterile scissors	
2. Assistant carefully removes previous dressing –	
Cavilon I M stick may be used to loosen edge of	
l egaderm if necessary.	
3. Clean insertion site and surrounding skin	To reduce surface debris and cleanse tubing.
with aqueous (non-alcohol) chlorhexidine	thereby reducing the risk of infection.
cleansing agent, starting at the catheter and	
working outward in a circular motion, allow to dry.	
Repeat for tubing – allow to dry.	To reduce skin flora present on catheter and around
Take special care not to pull on tubing.	connection.
4 Clean area again with sterile water and dry	Maintain asensis of insertion site
thoroughly with gauze	
5. Carefully check insertion site and sutures	Ensure no signs of infection or migration of line
6. Use Cavilon I M stick to wipe around skin area	Ennances adherence of transparent dressing
dressing will be placed, and allow to dry	
Coil or loop catheter tubing and secure	
with Steristrips prior to placing transparent	
dressing.	
7 To secure the dressing	To provide secure transparent asentic cover over
7. To secure the dressing	insertion site
• Cover area with IV3000 dressing, use sleek	
strips from dressing pack around the outside	
dressing.	FO DA
Secure catheter outside dressing to skin with	
Steristrips or tape with Duoderm base to	SAL COCOMMENT
prevent tension on line and dressing	
Exit line from side or bottom of dressing if	
possible to prevent baby's hands pulling out the	
line.	
8. Dispose of sharps and rubbish in designated	
receptacle, and clean trolley with Tuffie wipes.	
9 Documentation & monitoring	To maintain accurate record of line placement and
Take photograph of line in situ following	identify risk of catheter dislodgement.
dressing change and keep in red care plan.	,
Document procedure in clinical notes.	
Assess position and dressing integrity during	
cares and document on clinical notes.	
Doc ID: 4936 Version: 05 Issue Dat	e: 28 March 2018 Review Date: 28 March 2021
Facilitator Title Registered Nurses NICU	Department: NICU
I IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY	' FOR THE DAY OF PRINTING Page 21 of 24



3.6 Removal of CVL / UVC Care Bundle and disconnecting antibiotic lines

Indications

- UVC: Currently removed and changed routinely to CVL at 7 days.
- **CVL:** Lines are removed when infant's condition no longer necessitates its use or if complications require its removal.

NB: CVL gown pack not required for this procedure or disconnection of antibiotic extension

Disconnection of CVL medication (e.g. antibiotics, caffeine) extension: If an infant has had an infusion over time via a CVL, the extension may be left in the line until next line change OR removed using sterile gloves and chlorhexidine-alcohol prep pads while unscrewing and disconnecting. Ensure connection is thoroughly cleaned prior to unscrewing and disconnection.

Equipment

- Trolley
- Masks x2
- Sterile gloves
- Dressing pack
- Fine suture set (UVC)
- Transparent dressing (Tegaderm or Opsite) (CVL)
- Tape
- Chlorhexidine in alcohol cleansing agent for line
- Aqueous (non-alcohol) chlorhexidine cleansing agent for skin
- Cavilon[™] stick
- Sterile laboratory specimen container (if needed)

Procedure: Two nurses procedure

Acti	on	Rationale
1.	Perform hand hygiene	To minimise risk of infection
2.	Collect trolley cleaned with Tuffie wipes and allow to dry. Collect equipment, and arrange on cleaned extension arm of trolley.	To minimise risk of infection
3.	Put on masks and perform hand hygiene.	
4.	Assistant to open dressing pack and sterile gloves onto trolley. Sterile nurse to open and arrange sterile equipment on sterile field.	To avoid contamination of sterile field and minimise risk of infection
5.	TURN INFUSION OFF	Prolonged stasis can cause thrombus formation.
6.	 Remove dressing Assistant may use CavilonTM stick to loosen transparent dressing/ bridging tapes. 	To enable easy removal of dressing with forceps and prevent accidental tearing of
D = =	ID. 4000 Marsian OF Laure Datas OO Ma	rah 0040 Daview Dates 00 Marsh 0004
DOC	ID: 4936 Version: US ISSUE Date: 28 Ma	ICD 2018 Review Date: 28 March 2021

000101	1000	101010111	00	loodo Bato.	Eo maron Eo ro	nome bate.	Lo maron Loci
Facilitator Title		Registered Nurses NICU			Department:	NICU	
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING						PRINTING	Page 22 of 24



 Stabilise the CVL hub avoiding tension on the catheter. Stretching the dressing can assist and remove dressing with faragene. 	line. To maintain a clean field and allow for		
 7. Clean skin around insertion site with aqueous (non-alcohol) chlorhexidine cleansing agent. 	To minimise risk of infection at site		
 <u>Removal of CVL</u>: Grasp the catheter with forceps at insertion site and pull slowly 1cm parallel to the skin. Release and re-grasp the CVL at insertion site after each withdrawal. Ease line out with short smooth strokes. Stop if resistance is felt. Assistant to reposition limb and attempt removal again. If resistance persists, venous spasm may be the cause. Apply warm compress to limb for 15-20 minutes. Gently attempt removal again. <u>Never apply force</u>. Inspect catheter (without contaminating tip) to ensure catheter is complete. Place CVL tip in sterile container, check with medical staff whether the catheter tip is required to be sent to laboratory, if sepsis is suspected. Apply continuous pressure to catheter insertion site for 5-10 minutes. Dress CVL site with small gauze square and transparent dressing. Remove dressing after 48 hours. 	 Avoids excess tension on the line during withdrawal. Assists the catheter to slide smoothly along the vessel towards the insertion site Any excess pressure application during attempts to move catheter may result in catheter tearing or snapping inside vessel To prevent bleeding from site 		
 9. <u>Removal of UVC</u>: Remove suture with sterile scissors and forceps. Pull catheter from vessel slowly, over 5 minutes. UVC site left uncovered – do not nurse infant prone for minimum of 4 hours post removal 10. Remove gloves, dispose of equipment, clean trolley with 	To allow for visualisation and identify bleeding from umbilicus until scab formation complete.		
Tuffie wipe, and perform hand hygiene.			
Document procedure in clinical notes.			

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator Title		Registered Nurses NICU		Department:	NICU		
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING							



4. Evidence Base

4.1 Associated documents

- Waikato DHB SS NICU Medical Protocol: Asepsis protocol for central venous catheter insertion and central venous line maintenance (2654)
- Waikato DHB SS NICU Nursing Procedure: Arterial lines sampling, nursing management and removal (1638)

4.2 References

- NQIP (2009). Catheter-related Bloodstream Infection Project Consultation Draft. Guidance on preventing Central Venous Catheter-related Bloodstream Infections for New Zealand Hospitals. Retrieved Dec 2009 from <u>http://www.infectioncontrol.org.nz/catheter-related/Guidance%20document%20-%20FINAL%20%20_Dec%202009_.pdf</u>.
- Great Ormond Street Hospital for Children (2009). Clinical Guideline Antiseptic Skin Preparation – First Line use of 2% Chlorhexidine / 70% Isopropyl Alcohol for all Age Groups. Retrieved from <u>http://www.ich.ucl.ac.uk/clinical_information/clinical_guidelines/cpg_guidleine_001</u> 85/
- Department of Health (2013). *Guideline for hand hygiene*. Retrieved April 10, 2016 from http://www.Health.qld.gov.au
- Leick-Rude, M.K. & Haney, B. (2006). Midline Catheter Use in the Intensive Care Nursery. *Neonatal Network*, 25, 3.
- MacDonald M. G. & Ramasethu J. (2002). Atlas of Procedures in Neonatology (3rd Edition). Lippincott, Williams & Wilkins. Philadelphia.
- Nair, A. (2009) Asepsis Protocol for Percutaneous Central Venous Catheter Insertion and Central Venous Line Maintenance. *Waikato DHB Service Specific NICU Protocol.*
- Pettit J. & Wyckoff M.M. (2001). Guidelines for Practice Peripherally Inserted Central Catheters. *Guideline for Practice*. NANN Publication.
- Askar Kukkady, Pediatric Surgeon, Waikato Hospital. Personal communication October 5th 2012.
- Askar Kukkady, Pediatric Surgeon, Waikato Hospital and Lynette Lennox, IV CNS, Waikato DHB. Personal communication March 23, 2016.

Doc ID:	4936	Version:	05	Issue Date:	28 March 2018	Review Date:	28 March 2021
Facilitator Title		Registered Nurses NICU			Department:	NICU	
IF THIS DOCUMENT IS PRINTED, IT IS VALID ONLY FOR THE DAY OF PRINTING							